

# Dektite® Retrofit™

## - Pipe Flashings & Roofing Accessories

### APPLICATIONS

- Existing penetrations
- Repairs
- Difficult to access penetrations
- Hot & cold flues
- Vents & ducts




### FEATURES

- Wraps around existing or difficult to access pipes
- Snaps together in seconds - no loose clips or rivets needed
- Grips tight and stays tight
- The supple aluminium base conforms like magic
- Twenty year warranty - just fit it and forget it



### SPECIFICATIONS

CODE	PIPE mm	BASE mm	PITCH	COLOUR
RF 801	20-70	160	0-40°	Red,Black,Grey
RF 802	50-185	273	0-40°	Red,Black,Grey
RF 803	85-255	369	0-40°	Red,Black,Grey
RFS 4	235-425	780 x 680	0-40°	Grey

 EPDM - Perfect for approved flues!

E..P.D.M. withstands temperatures from -50 degrees C to 115 degrees C, and up to 150c degrees C intermittently

Dektite® EPDM polymer flashing have been officially tested by the Coal Corporation of Victoria, Australia and conform to all Australian and UK Standards on approved flue systems. Under no circumstances should any polymer flashing be installed on a non approved flue or an 'active' combustion heater flue

### INSTALLATION INSTRUCTIONS



**1** Trim the cone to suit pipe size using sharp tin snips.



**2** With clip in downstream position, wrap top of cone around pipe and engage metal teeth in opposing pockets starting at the top.



**3** To assist clip into pocket, place hand behind seam. Fasten clip with pliers or multigrips, working from top to base. Do not over crimp.



**4** Apply sealant to underside of Dektite® base and shape to roof by hand.



**5** Fasten flashing down and secure clip by placing a fastener either side of clip first.



**6** Apply sealant to top of crimp closure and any other potential leak areas.

### HOW TO RETROFIT A SQUARE PIPE

Due to the unique patented design of the Dektite® Retrofit™ a standard rule cannot be applied when sealing a square pipe or duct. For square penetrations simply measure around the side of the square, select the correct Dektite® Retrofit™ size and cut to the correct ring

as shown.

Note: When flashing a square pipe a bead of silicone should be applied along the junction between the EPDM and the pipe. Do not pull back the EPDM to apply the silicone as this can affect the Dektite® seal against a flat surface.

<b>Dektite® Retrofit Size</b>	<b>Square Pipe/Duct Length of Side (mm)</b>	<b>Cut to ring marked (mm)</b>
<b>RF 801</b>	<b>40</b>	<b>40-50</b>
	<b>50</b>	<b>50-60</b>
	<b>60</b>	<b>60-70</b>
<b>RF802</b>	<b>50</b>	<b>55-60</b>
	<b>60</b>	<b>65-80</b>
	<b>70</b>	<b>80-95</b>
	<b>80</b>	<b>95-105</b>
	<b>90</b>	<b>105-115</b>
	<b>100</b>	<b>115-130</b>
	<b>120</b>	<b>130-140</b>
<b>140</b>	<b>150-170</b>	
<b>RF 803</b>	<b>70</b>	<b>85-95</b>
	<b>80</b>	<b>85-95</b>
	<b>90</b>	<b>95-110</b>
	<b>100</b>	<b>120-130</b>
	<b>120</b>	<b>120-130</b>
	<b>140</b>	<b>145-160</b>
	<b>160</b>	<b>170-190</b>
	<b>180</b>	<b>210-230</b>
<b>200</b>	<b>240-255</b>	